

PRODUCT INFORMATION SHEET



One Zenex Circle • Cleveland, Ohio 44146
Toll Free: 866-217-5100 • Fax: 440-232-5101

Wheel Weight Remover

ZENEX NUMBER 494800

DESCRIPTION

Wheel Weight Remover is formulated to remove the gasket adhesive left behind after the wheel weights have been removed prior wheel balancing.

FEATURES AND BENEFITS

Spray on aluminum, alloy and steel wheels. The thick gel formula clings to wheel weights providing accurate application and contact time.

APPLICATIONS AND USES

Use to remove all wheel weight adhesive. Can also be used to remove gasket and thread locking adhesives.

DIRECTIONS FOR USE

1. Shake can vigorously for one minute after mixing ball begins to rattle.
2. Spray 8 to 12 inches from surface.
3. Allow several minutes to penetrate wheel weight adhesive.
4. Remove wheel weight gasket adhesive with a microfiber towel to prevent scratching surface. Rinse surface.
5. Repeat above if necessary.

CAUTION: May soften some plastics and paints.

SIZE / AVAILABILITY

- 20 oz. Aerosol
- Net Weight 14 oz.
- 12 per case

STATE RESTRICTION

None.



**Emergency
Phone Number
(800) 535-5053**

HMIS	
HEALTH	2
FLAMMABILITY	3
REACTIVITY	0
PERSONAL PROTECTION	B

